



**CR-DS505**  
**CR-D500**

YH1(S),YJ1(S)  
YL1(S)  
YU(S),YH1(S)  
YL1(S),YJ1(S)

# **SERVICE MANUAL**

---

RADIO RECEIVER

---

- Replace this Service Manual with "Revision Publishing" when it is issued.

**aiwa**  
S/M Code No. 09-003-343-6T2

SIMPLE  
DATA

# ELECTRICAL MAIN PARTS LIST - 1

NOTE: The characters in the suffix column indicate the part usage.

DS505YH1(S)	XX	B
DS505YJ1(S)	XX	C
DS505YL1(S)	XX	D
D500YU(S)	XX	F
D500YH1(S)	XX	H
D500YJ1(S)	XX	I
D500YL1(S)	XX	J

REF. NO	PARTS NO.	NO.	DESCRIPTION	SUFFIX
C 405	87-010-183-080	0E	C-CAP, S 2700P-50 B	ABCDE
C 455	87-010-183-080	0E	C-CAP, S 2700P-50 B	ABCDE
C 303	87-010-188-080	0E	CAP, CHIP 6800P	ABCDE
C 103	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	ABCDE
C 121	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	ABCDE
C 123	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	ABCDE
C 125	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	ABCDE
C 128	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	ABCDE
C 403	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	ABCDE
C 407	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	ABCDE
C 423	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	ABCDE
C 453	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	ABCDE
C 457	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	ABCDE
C 102	87-010-197-080	0E	CAP, CHIP 0.01 DM	ABCDE
C 110	87-010-197-080	0E	CAP, CHIP 0.01 DM	ABCDE
C 112	87-010-197-080	0E	CAP, CHIP 0.01 DM	ABCDE
C 114	87-010-197-080	0E	CAP, CHIP 0.01 DM	ABCDE
C 124	87-010-197-080	0E	CAP, CHIP 0.01 DM	ABCDE
C 130	87-010-197-080	0E	CAP, CHIP 0.01 DM	ABCDE
C 131	87-010-197-080	0E	CAP, CHIP 0.01 DM	ABCDE
C 132	87-010-197-080	0E	CAP, CHIP 0.01 DM	ABCDE
C 420	87-010-197-080	0E	CAP, CHIP 0.01 DM	ABCDE
C 108	87-010-324-080	0E	C-CAP, S 1P-50UJ	ABCDE
C 111	87-010-328-080	0E	C-CAP, S 5P-50 UJ	ABCDE
C 115	87-010-328-080	0E	C-CAP, S 5P-50 UJ	ABCDE
C 107	87-010-333-080	0E	S-CHIP UJ 10P	ABCDE
C 117	87-010-334-080	0E	C-CAP, S 12P-50 UJ	ABCDE
C 105	87-010-341-080	0E	C-CAP, S47P-50UJ	ABCDE
C 301	87-010-341-080	0E	C-CAP, S47P-50UJ	ABCDE
C 401	87-010-428-080	0E	C-CAP, S 0.015-25 B	ABCDE
C 451	87-010-428-080	0E	C-CAP, S 0.015-25 B	ABCDE
C 133	87-010-568-080	0E	C-CAP, S 150P-50 UJ	ABCDE
C 101	87-010-570-080	0E	C-CAP, S 220P-50 UJ	ABCDE
C 118	87-010-572-080	0E	C-CAP, S 330P-50 UJ	ABCDE
C 116	87-010-573-080	0E	C-CAP, S 390P-50 UJ	ABCDE
C 104	87-010-574-080	0E	C-CAP, S 470P-50 UJ	ABCDE
C 109	87-010-575-080	0E	C-CAP, S 560P-50 UJ	ABCDE
C 120	87-010-805-080	0E	CAP, S 1-16	ABCDE
C 122	87-010-805-080	0E	CAP, S 1-16	ABCDE
C 304	87-010-805-080	0E	CAP, S 1-16	ABCDE
C 126	87-016-526-080	0E	C-CAP, S 0.47-16 BK	ABCDE
C 402	87-016-526-080	0E	C-CAP, S 0.47-16 BK	ABCDE
C 452	87-016-526-080	0E	C-CAP, S 0.47-16 BK	ABCDE
IC 401	87-017-642-080	1D	IC, CXA1622M	ABCDE
VC 102	87-017-925-070	1A	C-VARI CAP, KV1460	ABCDE
VC 103	87-017-925-070	1A	C-VARI CAP, KV1460	ABCDE
Q 104	87-026-467-080	0E	TR, HN1C01F (0.3W)	ABCDE
IC 101	87-A21-407-040	1E	C-IC, TA2104BFN	ABCDE
VC 101	87-A40-462-040	1B	C-VARI-CAP, SVC347(S)	ABCDE
Q 102	89-115-884-080	0E	CHIP -TRANSISTER 2SA1588Y	ABCDE
Q 301	89-341-165-080	0E	CHIP TRANSISTOR 2SC4116GR	ABCDE
Q 302	89-341-165-080	0E	CHIP TRANSISTOR 2SC4116GR	ABCDE
Q 101	89-342-153-080	0E	TR, 2SC4215	ABCDE
Q 103	89-342-153-080	0E	TR, 2SC4215	ABCDE
Q 105	89-342-153-080	0E	TR, 2SC4215	ABCDE
C 405	87-010-183-080	0E	C-CAP, S 2700P-50 B	FGHIJK
C 455	87-010-183-080	0E	C-CAP, S 2700P-50 B	FGHIJK
C 303	87-010-188-080	0E	CAP, CHIP 6800P	FGHIJK
C 103	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	FGHIJK
C 121	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	FGHIJK
C 123	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	FGHIJK
C 125	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	FGHIJK
C 128	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	FGHIJK
C 403	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	FGHIJK
C 407	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	FGHIJK
C 423	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	FGHIJK
C 453	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	FGHIJK
C 457	87-010-196-080	0E	CHIP CAPACITOR, 0.1-25	FGHIJK
C 102	87-010-197-080	0E	CAP, CHIP 0.01 DM	FGHIJK
C 110	87-010-197-080	0E	CAP, CHIP 0.01 DM	FGHIJK
C 112	87-010-197-080	0E	CAP, CHIP 0.01 DM	FGHIJK
C 114	87-010-197-080	0E	CAP, CHIP 0.01 DM	FGHIJK
C 124	87-010-197-080	0E	CAP, CHIP 0.01 DM	FGHIJK
C 130	87-010-197-080	0E	CAP, CHIP 0.01 DM	FGHIJK
C 131	87-010-197-080	0E	CAP, CHIP 0.01 DM	FGHIJK
C 132	87-010-197-080	0E	CAP, CHIP 0.01 DM	FGHIJK
C 420	87-010-197-080	0E	CAP, CHIP 0.01 DM	FGHIJK
C 108	87-010-324-080	0E	C-CAP, S 1P-50UJ	FGHIJK
C 111	87-010-328-080	0E	C-CAP, S 5P-50 UJ	FGHIJK
C 115	87-010-328-080	0E	C-CAP, S 5P-50 UJ	FGHIJK
C 107	87-010-333-080	0E	S-CHIP UJ 10P	FGHIJK


## ELECTRICAL MAIN PARTS LIST - 2

C	117	87-010-334-080	0E	C-CAP, S 12P-50	UJ	FGHIJK
C	105	87-010-341-080	0E	C-CAP, S47P-50UJ		FGHIJK
C	301	87-010-341-080	0E	C-CAP, S47P-50UJ		FGHIJK
C	401	87-010-428-080	0E	C-CAP, S 0.015-25	B	FGHIJK
C	451	87-010-428-080	0E	C-CAP, S 0.015-25	B	FGHIJK
C	133	87-010-568-080	0E	C-CAP, S 150P-50	UJ	FGHIJK
C	101	87-010-570-080	0E	C-CAP, S 220P-50	UJ	FGHIJK
C	118	87-010-572-080	0E	C-CAP, S 330P-50	UJ	FGHIJK
C	116	87-010-573-080	0E	C-CAP, S 390P-50	UJ	FGHIJK
C	104	87-010-574-080	0E	C-CAP, S 470P-50	UJ	FGHIJK
C	109	87-010-575-080	0E	C-CAP, S 560P-50	UJ	FGHIJK
C	120	87-010-805-080	0E	CAP, S 1-16		FGHIJK
C	122	87-010-805-080	0E	CAP, S 1-16		FGHIJK
C	304	87-010-805-080	0E	CAP, S 1-16		FGHIJK
C	126	87-016-526-080	0E	C-CAP, S 0.47-16	BK	FGHIJK
C	402	87-016-526-080	0E	C-CAP, S 0.47-16	BK	FGHIJK
C	452	87-016-526-080	0E	C-CAP, S 0.47-16	BK	FGHIJK
IC	401	87-017-642-080	1D	IC, CXA1622M		FGHIJK
VC	102	87-017-925-070	1A	C-VARI CAP, KV1460		FGHIJK
VC	103	87-017-925-070	1A	C-VARI CAP, KV1460		FGHIJK
Q	104	87-026-467-080	0E	TR, HN1C01F (0.3W)		FGHIJK
IC	101	87-A21-407-040	1E	C-IC, TA2104BFN		FGHIJK
VC	101	87-A40-462-040	1B	C-VARI-CAP, SVC347(S)		FGHIJK
Q	102	89-115-884-080	0E	CHIP -TRANSISTER 2SA1588Y		FGHIJK
Q	301	89-341-165-080	0E	CHIP TRANSISTOR 2SC4116GR		FGHIJK
Q	302	89-341-165-080	0E	CHIP TRANSISTOR 2SC4116GR		FGHIJK
Q	101	89-342-153-080	0E	TR, 2SC4215		FGHIJK
Q	103	89-342-153-080	0E	TR, 2SC4215		FGHIJK
Q	105	89-342-153-080	0E	TR, 2SC4215		FGHIJK
D	503	87-001-553-080	0E	C-DIODE ISS322		ABCDE
D	504	87-001-553-080	0E	C-DIODE ISS322		ABCDE
D	505	87-001-553-080	0E	C-DIODE ISS322		ABCDE
D	506	87-001-553-080	0E	C-DIODE ISS322		ABCDE
D	507	87-001-553-080	0E	C-DIODE ISS322		ABCDE
D	508	87-001-553-080	0E	C-DIODE ISS322		ABCDE
C	502	87-010-800-080	0E	C-CAP TN 1-10(A2)		ABCDE
C	503	87-010-831-080	0E	C-CAP, U, 0.1-16F		ABCDE
C	509	87-010-831-080	0E	C-CAP, U, 0.1-16F		ABCDE
C	510	87-010-831-080	0E	C-CAP, U, 0.1-16F		ABCDE
C	511	87-010-831-080	0E	C-CAP, U, 0.1-16F		ABCDE
C	506	87-012-174-080	0E	CAP CHIP CERA SS 12P CHJ		ABCDE
C	507	87-012-176-080	0E	CAP 15P		ABCDE
C	501	87-012-286-080	0E	CAP, U 0.01-25		ABCDE
C	504	87-016-057-080	1B	C-CAP, TN 47-4/F9.5		ABCDE
C	508	87-016-526-080	0E	C-CAP, S 0.47-16 BK		ABCDE
S	502	87-A90-871-080	1A	C-SW, SL 1-1-2 SSSS810701		ABCDE
S	516	87-A90-871-080	1A	C-SW, SL 1-1-2 SSSS810701		ABCDE
Q	504	89-115-884-080	0E	CHIP -TRANSISTER 2SA1588Y		ABCDE
Q	501	89-341-165-080	0E	CHIP TRANSISTOR 2SC4116GR		ABCDE
Q	503	89-341-165-080	0E	CHIP TRANSISTOR 2SC4116GR		ABCDE
Q	505	89-341-165-080	0E	CHIP TRANSISTOR 2SC4116GR		ABCDE
D	502	89-508-804-080	1A	CHIP FET 2SK880Y		ABCDE
D	503	87-001-553-080	0E	C-DIODE ISS322		FGHIJK
D	504	87-001-553-080	0E	C-DIODE ISS322		FGHIJK
D	505	87-001-553-080	0E	C-DIODE ISS322		FGHIJK
D	506	87-001-553-080	0E	C-DIODE ISS322		FGHIJK
D	507	87-001-553-080	0E	C-DIODE ISS322		FGHIJK
D	508	87-001-553-080	0E	C-DIODE ISS322		FGHIJK
C	502	87-010-800-080	0E	C-CAP TN 1-10(A2)		FGHIJK
C	503	87-010-831-080	0E	C-CAP, U, 0.1-16F		FGHIJK
C	509	87-010-831-080	0E	C-CAP, U, 0.1-16F		FGHIJK
C	510	87-010-831-080	0E	C-CAP, U, 0.1-16F		FGHIJK
C	511	87-010-831-080	0E	C-CAP, U, 0.1-16F		FGHIJK
C	506	87-012-174-080	0E	CAP CHIP CERA SS 12P CHJ		FGHIJK
C	507	87-012-176-080	0E	CAP 15P		FGHIJK
C	501	87-012-286-080	0E	CAP, U 0.01-25		FGHIJK
C	504	87-016-057-080	1B	C-CAP, TN 47-4/F9.5		FGHIJK
C	508	87-016-526-080	0E	C-CAP, S 0.47-16 BK		FGHIJK
S	502	87-A90-871-080	1A	C-SW, SL 1-1-2 SSSS810701		FGHIJK
S	516	87-A90-871-080	1A	C-SW, SL 1-1-2 SSSS810701		FGHIJK
Q	504	89-115-884-080	0E	CHIP -TRANSISTER 2SA1588Y		FGHIJK
Q	501	89-341-165-080	0E	CHIP TRANSISTOR 2SC4116GR		FGHIJK
Q	503	89-341-165-080	0E	CHIP TRANSISTOR 2SC4116GR		FGHIJK
Q	505	89-341-165-080	0E	CHIP TRANSISTOR 2SC4116GR		FGHIJK
D	502	89-508-804-080	1A	CHIP FET 2SK880Y		FGHIJK
SP	401	84-TM1-635-010	SP	DIA36		ABCDE
L	104	87-003-152-080	0E	COIL, 100UH		ABCDE
L	401	87-003-383-010	1A	COIL, 1UH-S		ABCDE
L	402	87-003-383-010	1A	COIL, 1UH-S		ABCDE
L	451	87-003-383-010	1A	COIL, 1UH-S		ABCDE
C	406	87-010-097-010	CAP, E	3.3-6.3 K AU		ABCDE
C	456	87-010-097-010	CAP, E	3.3-6.3 K AU		ABCDE
C	127	87-010-098-010	CAP, E	4.7-6.3 K AU		ABCDE
C	421	87-010-420-080	0E	CAP, E 10-6.3 5L		ABCDE
C	422	87-010-420-080	0E	CAP, E 10-6.3 5L		ABCDE
C	129	87-010-482-080	1A	CAP, E 220-4 M 12.5L SRA		ABCDE
C	424	87-010-482-080	1A	CAP, E 220-4 M 12.5L SRA		ABCDE
C	302	87-010-501-080	0E	E/CAP GAS 47-4		ABCDE
C	408	87-010-588-010	0E	ELECT 220-2		ABCDE
C	458	87-010-588-010	0E	ELECT 220-2		ABCDE
D	301	87-020-465-080	0E	DIODE, 1SS133 (110MA)		ABCDE
D	302	87-020-465-080	0E	DIODE, 1SS133 (110MA)		ABCDE
S	401	87-036-127-010	1A	SLIDE SWITCH		ABCDE

## ELECTRICAL MAIN PARTS LIST - 3

J	401	87-A60-760-010	1A JACK, 3.5 ST W/O SW	ABCDE
X	501	87-A70-187-010	1B VIB, XTAL 75KHZ CFV206	ABCDE
BPF	101	87-A90-749-010	0E FLTR, GFMB5	ABCDE
CF	102	87-A90-991-010	0E FLTR, SFE10.7 MS239-A	ABCDE
CF	103	87-A91-094-010	1A FLTR, CDA10.7 MG80A	ABCDE
S	101	87-A91-152-010	1A SW, SL 1-1-2 SSSS212-11-A	ABCDE
S	402	87-A91-152-010	1A SW, SL 1-1-2 SSSS212-11-A	ABCDE
CF	101	87-A91-162-010	0E FLTR, PFS450A7	ABCDE
T	101	87-A91-366-010	1A IFT, MW 5PLG	ABCDE
TC	101	87-A91-392-010	TRIMMER, 20P	ABCDE
S	501	87-A91-732-010	SW, SL 2-2-2 ALZ	ABCDE
LED	501	87-A91-734-080	C-LED, PG1113F	ABCDE
VR	401	87-A91-735-010	VR, RTRY 50KX1 1 H RK14J11A	ABCDE
L	102	8A-RC4-601-010	COIL, FM RF	ABCDE
L	103	8A-RC4-602-010	COIL, FM OSC	ABCDE
L	101	8A-RC4-603-010	BAR-ANT, MW	ABCDE
T	301	8A-RC4-604-010	COIL, D-D CON	ABCDE
LCD	101	8A-RC4-607-010	LCD, ARC-4	ABCDE
L	104	87-003-152-080	0E COIL, 100UH	FGHIJK
L	401	87-003-383-010	1A COIL, 1UH-S	FGHIJK
L	402	87-003-383-010	1A COIL, 1UH-S	FGHIJK
L	451	87-003-383-010	1A COIL, 1UH-S	FGHIJK
C	406	87-010-097-010	CAP, E 3.3-6.3 K AU	FGHIJK
C	456	87-010-097-010	CAP, E 3.3-6.3 K AU	FGHIJK
C	127	87-010-098-010	CAP, E 4.7-6.3 K AU	FGHIJK
C	421	87-010-420-080	0E CAP, E 10-6.3 5L	FGHIJK
C	422	87-010-420-080	0E CAP, E 10-6.3 5L	FGHIJK
C	129	87-010-482-080	1A CAP, E 220-4 M 12.5L SRA	FGHIJK
C	424	87-010-482-080	1A CAP, E 220-4 M 12.5L SRA	FGHIJK
C	302	87-010-501-080	0E E/CAP GAS 47-4	FGHIJK
C	408	87-010-588-010	0E ELECT 220-2	FGHIJK
C	458	87-010-588-010	0E ELECT 220-2	FGHIJK
D	301	87-020-465-080	0E DIODE, 1SS133 (110MA)	FGHIJK
D	302	87-020-465-080	0E DIODE, 1SS133 (110MA)	FGHIJK
S	401	87-036-127-010	1A SLIDE SWITCH	FGHIJK
J	401	87-A60-760-010	1A JACK, 3.5 ST W/O SW	FGHIJK
X	501	87-A70-187-010	1B VIB, XTAL 75KHZ CFV206	FGHIJK
BPF	101	87-A90-749-010	0E FLTR, GFMB5	FGHIJK
CF	102	87-A90-991-010	0E FLTR, SFE10.7 MS239-A	FGHIJK
CF	103	87-A91-094-010	1A FLTR, CDA10.7 MG80A	FGHIJK
S	101	87-A91-152-010	1A SW, SL 1-1-2 SSSS212-11-A	FGHIJK
S	402	87-A91-152-010	1A SW, SL 1-1-2 SSSS212-11-A	FGHIJK
CF	101	87-A91-162-010	0E FLTR, PFS450A7	FGHIJK
T	101	87-A91-366-010	1A IFT, MW 5PLG	FGHIJK
TC	101	87-A91-392-010	TRIMMER, 20P	FGHIJK
S	501	87-A91-732-010	SW, SL 2-2-2 ALZ	FGHIJK
LED	501	87-A91-734-080	C-LED, PG1113F	FGHIJK
VR	401	87-A91-735-010	VR, RTRY 50KX1 1 H RK14J11A	FGHIJK
L	102	8A-RC4-601-010	COIL, FM RF	FGHIJK
L	103	8A-RC4-602-010	COIL, FM OSC	FGHIJK
L	101	8A-RC4-603-010	BAR-ANT, MW	FGHIJK
T	301	8A-RC4-604-010	COIL, D-D CON	FGHIJK
LCD	101	8A-RC4-607-010	LCD, ARC-4	FGHIJK
C	502	87-010-504-080	0E CAP, CHIP TANTALUM 0.47-25	ABCDE
C	504	87-016-436-080	1B C-CAP, TN 47-4(B2)	ABCDE
IC	502	87-A20-755-080	1B C-IC, AK93C45AF	ABCDE
IC	501	87-A21-605-010	1H C-IC, TC9318FA-056	ABCDE
C	502	87-010-504-080	0E CAP, CHIP TANTALUM 0.47-25	FGHIJK
C	504	87-016-436-080	1B C-CAP, TN 47-4(B2)	FGHIJK
IC	502	87-A20-755-080	1B C-IC, AK93C45AF	FGHIJK
IC	501	87-A21-605-010	1H C-IC, TC9318FA-056	FGHIJK

## SCHEMATIC DIAGRAM-1



# MECHANICAL PARTS LIST - 1

NOTE: The characters in the suffix column indicate the part usage.

DS505YH1(S) .....	XX.....	B.....
DS505YJ1(S) .....	XX.....	C.....
DS505YL1(S) .....	XX.....	D.....
D500YU(S) .....	XX.....	F.....
D500YH1(S) .....	XX.....	H.....
D500YJ1(S) .....	XX.....	I.....
D500YLL1(S) .....	XX.....	J.....

REF. NO	PARTS NO.	NO.	DESCRIPTION	SUFFIX
	8A-RC4-001-010		CABI, FRONT	ABCDE.....
	8A-RC4-002-010		CABI, REAR Y	.B..DE.....
	8A-RC4-003-010		PANEL, FRONT	ABCDE.....
	8A-RC4-004-010		LID, BATT	ABCDE.....
	8A-RC4-012-010		WINDOW, LCD	ABCDE.....
	8A-RC4-013-010		CABI, REAR YZ	A.....
	8A-RC4-014-010		CABI, REAR YJ	.C.....
	8A-RC4-004-010		LID, BATT	FGHIJK.....
	8A-RC4-012-010		WINDOW, LCD	FGHIJK.....
	8A-RC5-001-010		CABI, FRONT	FGHIJK.....
	8A-RC5-002-010		PANEL, FRONT	FGHIJK.....
	8A-RC5-006-010		CABI, REAR Y	.H..JK.....
	8A-RC5-007-010		CABI, REAR YU	F.....
	8A-RC5-008-010		CABI, REAR YZ	.G.....
	8A-RC5-009-010		CABI, REAR YJ	.I.....
	8A-RC4-005-010		BTN, PRESET	ABCDE.....
	8A-RC4-006-010		BTN, BAND/LIGHT	ABCDE.....
	8A-RC4-007-010		BTN, TUNE/MEMO	ABCDE.....
	8A-RC4-008-010		KNOB, SL HOLD	ABCDE.....
	8A-RC4-009-010		KNOB, SL POWER	ABCDE.....
	8A-RC4-010-010		KNOB, SL MO/ST	ABCDE.....
	8A-RC4-011-010		KNOB, SL S-BASS	ABCDE.....
	8A-RC4-005-010		BTN, PRESET	FGHIJK.....
	8A-RC4-008-010		KNOB, SL HOLD	FGHIJK.....
	8A-RC4-009-010		KNOB, SL POWER	FGHIJK.....
	8A-RC4-010-010		KNOB, SL MO/ST	FGHIJK.....
	8A-RC5-003-010		BTN, BAND/LIGHT	FGHIJK.....
	8A-RC5-004-010		BTN, TUNE/MEMO	FGHIJK.....
	8A-RC5-005-010		KNOB, SL S-BASS	FGHIJK.....
	8A-RC4-201-010		LENS, LCD	ABCDE.....
	8A-RC4-202-010		HLDR, AM ANT	ABCDE.....
	8A-RC4-203-010		HLDR, JACK	ABCDE.....
	8A-RC4-204-010		HLDR, PRESET	ABCDE.....
	8A-RC4-205-010		HLDR, LIGHT/MEMO	ABCDE.....
	8A-RC4-206-010		COVER, LCD	ABCDE.....
	8A-RC4-208-010		BAT-CONTACT, (+)	ABCDE.....
	8A-RC4-209-010		BAT-CONTACT, (-)	ABCDE.....
	8A-RC4-210-010		BAT-CONTACT, (++)	ABCDE.....
	8A-RC4-211-010		CONN, RUBBER LCD	ABCDE.....
	8A-RC4-201-010		LENS, LCD	FGHIJK.....
	8A-RC4-202-010		HLDR, AM ANT	FGHIJK.....
	8A-RC4-203-010		HLDR, JACK	FGHIJK.....
	8A-RC4-204-010		HLDR, PRESET	FGHIJK.....
	8A-RC4-205-010		HLDR, LIGHT/MEMO	FGHIJK.....
	8A-RC4-206-010		COVER, LCD	FGHIJK.....
	8A-RC4-208-010		BAT-CONTACT, (+)	FGHIJK.....
	8A-RC4-209-010		BAT-CONTACT, (-)	FGHIJK.....
	8A-RC4-210-010		BAT-CONTACT, (++)	FGHIJK.....
	8A-RC4-211-010		CONN, RUBBER LCD	FGHIJK.....

## ACCESSORIES LIST

NOTE: The characters in the suffix column indicate the part usage.

DS505YH1(S)	XX	B
DS505YJ1(S)	XX	C
DS505YL1(S)	XX	D
D500YU(S)	XX	F
D500YH1(S)	XX	H
D500YJ1(S)	XX	I
D500YLL(S)	XX	J

REF. NO	PARTS NO.	NO.	DESCRIPTION	SUFFIX
8A-RC4-902-010	IB	YHJ(ECC)C	.BC	.....
8A-RC4-904-010	IB	YL(3L)C	..DE	.....
8A-RC4-905-010	IB	YZ(EGF)C	A	.....
8A-RC4-906-010	IB	YZ(SID)C	A	.....
8A-RC4-907-010	IB	YZ(PHNCZ)C	A	.....
8A-RC5-901-010	IB	YU(3L)C	..F	.....
8A-RC5-902-010	IB	YHJ(ECC)C	..HI	.....
8A-RC5-904-010	IB	YL(3L)C	..JK	.....
8A-RC5-905-010	IB	YZ(EGF)C	..G	.....
8A-RC5-906-010	IB	YZ(SID)C	..G	.....
8A-RC5-907-010	IB	YZ(PHNCZ)C	..G	.....
87-B30-240-010	1H	HEADPHONE, HP-M035	ABCDE	.....
87-B30-124-110	1E	HEADPHONE, HP-M028	..F	.....
87-B30-240-010	1H	HEADPHONE, HP-M035	....GHIJK	.....



**アイワ株式会社** 〒110-8710 東京都台東区池之端1-2-11 ☎ 03(3827) 3111 (代表)  
**AIWA CO., LTD.** 2-11, IKENOHATA 1-CHOME, TAITO-KU, TOKYO 110-8710, JAPAN TEL:03 (3827) 3111  
931196 Printed in Singapore